

# BATHROOM Machineries

495 Main Street Murphys CA 95247  
(209) 728-2031 FAX (209) 728-2320

## “J” Hook Installation Instructions

Locate ceiling joists (or other backing) for proper support. Space the J-Hooks around the curtain ring as evenly as possible. Drill a 1/2" hole off-center in the bottom of the curtain ring at the location of each J-Hook. De-burr hole, apply silicone adhesive and insert the J-Hook. (See illustration).

